




Instruction Manual

Unique SPC-1 Regulating Valve



TD 461-842

Declaration of Conformity

The designating company

Alfa Laval

Company Name

Albuen 31, DK-6000 Kolding, Denmark

Address

+45 79 32 22 00

Phone No.

hereby declare that

Unique SPC-1 Series Valve

Denomination

Regulating Valve

Type

2008

Year

is in conformity with the following directive:

- Machinery Directive 98/37/EEC
- Pressure Equipment Directive 97/23/EC category 1 and subjected to assessment procedure Module A.

**Manager, Product Centres,
Compact Heat Exchangers & Fluid Handling**

Title

Bjarne Søndergaard

Name

Alfa Laval Kolding

Company



Signature

Designation



The information contained herein is correct at the time of issue but may be subject to change without prior notice.

1. Safety	6
1.1 Important information	6
1.2 Warning signs	6
1.3 Safety precautions	7
2. Installation	8
2.1. Unpacking/Delivery	8
2.2. General installation	9
2.3. Welding	10
3. Operation	11
3.1 Operation	11
3.2 Trouble shooting	13
3.3 Recommended cleaning	14
4. Maintenance	16
4.1 General maintenance	17
4.2 Dismantling of valve	18
4.3 Plug seal replacement	18
4.4 Assembly of valve	18
4.5 Positioner end	19
4.6 Actuator bushing replacement	20
4.7 Dismantling of optional maintainable actuator	20
4.8 Assembly of optional maintainable actuator	20
4.9 Reversing optional maintainable actuator operation	20
5. Technical data	21
5.1 Technical data	21
6. Parts List and Service Kits	22
6.1 <i>Unique</i> SPC-1 - 38-101.6 mm	22
6.2 Maintainable actuator	24

1.1 Important information

1.2 Warning signs

1. Safety

*Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs.*

Always read the manual before using the valve!

WARNING!

Indicates that special procedures **must** be followed to avoid severe personal injury.

CAUTION!

Indicates that special procedures **must** be followed to avoid damage to the valve.

NOTE!

Indicates important information to simplify or clarify practices.

General warning:



Caustic agents:



All warnings in the manual are summarized on this page.

Pay special attention to the instructions below so that severe personal injury and/or damage to the valve are avoided.

Installation

- **Always** read the technical data thoroughly (see chapter 5).
- **Always** release compressed air after use.
- **Never** touch the moving parts if the actuator is supplied with compressed air.
- **Never** touch the valve or the pipelines when processing hot liquids or when sterilizing.
- **Never** dismantle the valve with valve and pipelines under pressure.
- **Never** dismantle the valve when it is hot.



Operation

- **Never** dismantle the valve with valve and pipelines under pressure.
- **Never** dismantle the valve when it is hot.
- **Always** read the technical data thoroughly (see chapter 5).
- **Always** release compressed air after use.
- **Never** touch the valve or the pipelines when processing hot liquids or when sterilizing.
- **Never** touch the moving parts if the actuator is supplied with compressed air.
- **Always** rinse well with clean water after the cleaning.



Always handle lye and acid with great care.



Maintenance

- **Always** read the technical data thoroughly (see chapter 5).
- **Always** release compressed air after use.
- **Never** service the valve when it is hot.
- **Never** service the valve with valve and pipelines under pressure.
- **Never** stick your fingers through the valve ports if the actuator is supplied with compressed air.
- **Never** touch the moving parts if the actuator is supplied with compressed air.



The instruction manual is part of the delivery. Study the instructions carefully.

The items refer to parts list and service kits section.

The valve is supplied as separate parts as standard (for welding).

The valve is assembled before delivery, if it is supplied with fittings.

Step 1

CAUTION!


Alfa Laval cannot be held responsible for incorrect unpacking.

Check the delivery for:

1. Complete valve.
2. Delivery note.
3. Instruction Manual.

2a

1. Complete actuator.
2. Bonnet (20).
3. Clamp (19).
4. Valve plug (23).
5. Valve body (22).
6. Spring connection piece (42)
7. Positioner yoke (44)
8. Spring (46)
9. Positioner (47)



Step 3

Remove possible packing materials from the valve/valve parts.

Inspect the valve/valve parts for visible transport damages.

Avoid damaging the valve/valve parts.

Study the instructions carefully and pay special attention to the warnings!
The valve has welding ends as standard but can also be supplied with fittings.

Step1

- **Always** read the technical data thoroughly (see chapter 5).
- **Always** release compressed air after use.



CAUTION!

Alfa Laval cannot be held responsible for incorrect installation.

Step 2

Never touch the moving parts if the actuator is supplied with compressed air.

Moving parts!



TD 461-844_2


Step 3

Avoid stressing the valve.

Pay special attention to:

- Vibrations.
- Thermal expansion of the pipelines.
- Excessive welding.
- Overloading of the pipelines.

Risk of damage!




TD461-845

Study the instructions carefully.
The valve is supplied as separate parts to facilitate the welding.
The items refer to the parts list and service kits section.
Check the valve for smooth operation after welding.

Step 1


Assemble the valve in accordance with the steps in section 4.4.

Pay special attention to the warnings!

**Step 2****Pre-use check:**

1. Supply compressed air to the actuator.
2. Open and close the valve several times to ensure that it operates smoothly.

Pay special attention to the warnings!



Study the instructions carefully and pay special attention to the warnings!
Ensure that the valve operates smoothly.
The items refer to the parts list and service kits section.

Step 1


- **Always** read the technical data thoroughly (see chapter 5).
- **Always** release compressed air after use.

CAUTION!


Alfa Laval cannot be held responsible for incorrect operation.

Step 2


Never touch the valve or the pipelines when processing hot liquids or when sterilizing.

**Step 3**

Never touch the moving parts if the actuator is supplied with compressed air.

**Step 4****Lubrication of valves:**

1. Ensure smooth movement between lip seal (25) and plug stem (23).
2. Lubricate with Klüber Paraliq GTE 703 if necessary. (see section 4.1)



Step 5**Lubrication of actuator**

1. Ensure smooth movement of the actuator (the actuator is lubricated before delivery).
2. Lubricate O-ring(s) with Molykote Longterm 2 plus if necessary.



TD 461-566

*Pay attention to possible faults. Study the instructions carefully.
The items refer to the parts list and service kits section*

NOTE!

Study the maintenance instructions carefully before replacing worn parts. - See section 4.1!

Problem	Cause/result	Repair
External product leakage	Worn or product affected lip seal and/or O-ring	<ul style="list-style-type: none"> - Replace the seals - Replace with seals of a different rubber grade
Internal product leakage	<ul style="list-style-type: none"> - Worn or product affected plug seal - Product deposits on the seat and/or plug - The product pressure on the plug is too high 	<ul style="list-style-type: none"> - Replace the seal - Replace with a seal of a different rubber grade - Frequent cleaning - Reduce product pressure
Water hammer	The flow direction is the same as the closing direction	- The flow direction should be against the closing direction
The valve does not open/close	- The pressure on the plug is too high	- Reduce the product pressure
Deviation in the flow regulation	- Mechanical parts have come loose (vibrations)	- Tighten and adjust
Actuator does not regulate	<ul style="list-style-type: none"> - No air - Actuator errors - Positioner errors 	<ul style="list-style-type: none"> Check air supply - Return the actuator to the supplier - Check positioner (see positioner instruction)

The valve is designed for cleaning in place (CIP). CIP = Cleaning In Place.
 Study the instructions carefully and pay special attention to the warnings!
 NaOH = Caustic Soda.
 HNO₃ = Nitric acid.

Step 1

Always handle lye and acid with great care.

Caustic danger!




Always use
rubber gloves!



Always use
protective goggles!


Step 2

Never touch the valve or the pipelines when sterilizing.




TD 461-848

Burning danger!

**Step 3**

Clean the plug and the seats correctly.
Pay special attention to the warnings!
Lift and lower valve plug momentarily!

Shut-off valve



TD 461-552.1

Step 4**Examples of cleaning agents:**

Use clean water, free from chlorides.

1. 1% by weight NaOH at 70° C

1 kg NaOH	+	100 l water	= Cleaning agent
--------------	---	----------------	------------------


2.2 l 33% NaOH	+	100 l water	= Cleaning agent
-------------------	---	----------------	------------------

2. 0.5% by weight HNO₃ at 70° C

0.7 l 53% HNO ₃	+	100 l water	= Cleaning agent
-------------------------------	---	----------------	------------------

Step 5

1. Avoid excessive concentration of the cleaning agent
2. Adjust the cleaning flow to the process
3. **Always** rinse well with clean water after the cleaning.

**Step 6****NOTE!**

The cleaning agents must be stored/disposed of in accordance with current rules/directives.

Maintain the valve regularly.

Study the instructions carefully and pay special attention to the warnings!

Always keep spare rubber seals and lip seals in stock.

Step 1



- **Always** read the technical data thoroughly (see chapter 5).
- **Always** release the compressed air after use.


CAUTION!

All scrap must be stored/disposed of in accordance with current rules/directives.

Step 2




- **Never** service the valve when it is hot.
- **Never** service the valve with valve and pipelines under pressure.



Step 3




Never stick your fingers through the valve ports if the actuator is supplied with compressed air.



Step 4



Never touch the moving parts if the actuator is supplied with compressed air.



Maintain the valve regularly.
 Study the instructions carefully.
 Always keep spare rubber seals and lip seals in stock.
 Check the valve for smooth operation after service.


Below are some guidelines for maintenance and lubrication intervals. Please note that the guidelines are for normal working conditions in one shift.

	Product wetted seals	Actuator bushings complete
Preventive maintenance	Replace after 12 months depending on working conditions	Replace after 5 years depending on working conditions
Maintenance after leakage (leakage normally starts slowly)	Replace at the end of the day	Replace when possible
Planned maintenance	<ul style="list-style-type: none"> - Regular inspection for leakage and smooth operation - Keep a record of the valve - Use the statistics for planning of inspections Replace after leakage	<ul style="list-style-type: none"> - Regular inspection for leakage and smooth operation - Keep a record of the actuator - Use the statistics for planning of inspections Replace after leakage
Lubrication	Before fitting Klüber Paraliq GTE 703 or similar USDA H1 approved oil/grease	Before fitting Molykote Longterm 2 plus

Pre-use check:

1. Supply compressed air to the actuator.
2. Open and close the valve several times to ensure that it operates smoothly.

Pay special attention to the warnings!



Recommended spare parts

Service kits (see chapter 6)

4.2 Dismantling of valve

4.3 Plug seal replacement

4.4 Assembly of valve

Study the instructions carefully. The items refer to the parts list and service kits section. Handle scrap correctly.

NC = Normally closed.


NO = Normally open.

4.2 Dismantling of valve

1. Supply compressed air to the actuator (only NC).
2. Loosen and remove clamp.
3. Release compressed air (only NC).
4. Lift away the actuator.
5. Unscrew and remove valve plug.
6. Remove O-ring, lip seal and bushing in bonnet.
(Use bushing tool and rubber mallet).


Pay special attention to the warnings!

Note! For plug seal replacement please see section 4.3.



4.3 Elastomer seat ring replacement

1. Remove old seal ring using a knife, screwdriver or similar.
Be careful not to damage metal parts.
2. Pre-mount plug seal without pressing it into the groove.
3. Squeeze plug seal into the groove using opposite pressure points.
4. Release compressed air behind plug seal.




4.4 Assembly of valve

Reverse order of 4.2, Dismantling of valve.

Lubricate O-ring (21) and lip seal (25) with Klüber Paraliq GTE 703.

1. Remove the air hose connections of the positioner (47) and the actuator.
2. Loosen the screws and lift off the positioner from its yoke (44).
3. Remove the positioner spring (46) and unscrew the spring connection piece (42) from the actuator spindle.
4. Unscrew the positioner yoke (44) from the cylinder.
5. Remove the guide ring (45) and the O-ring. (8)



4.6 Actuator bushing replacement -

4. Maintenance

4.7 Dismantling of optional maintainable actuator

4.8 Assembly of optional maintainable actuator

4.9 Reversing optional maintainable actuator operation

Study the instructions carefully.


The items refer to the parts list and service kits section.

Handle scrap correctly.

Service tool: See Spare Parts


4.6 Actuator bushing replacement

1. Unscrew and remove O-rings.
2. Lubricate O-rings with Molykote Longterm 2 plus before fitting.
3. Fit bushings and O-rings. Be careful not to overtighten.



4.7 Dismantling of optional maintainable actuator

1. Rotate cylinder (1).
2. Remove lock wire (10) and pull away cylinder (1).
3. Unscrew nuts (18) and remove yoke (13).
4. Unscrew bottom bushing (6).
5. Remove stem (2) with O-ring (3) and spring assembly (14).
6. Remove O-rings and support disc.



4.8 Assembly of optional maintainable actuator


Reverse order of 4.6. Dismantling of actuator.

Lubricate O-ring (3,7,11) with Molykote Longterm 2 plus before fitting.

4.9 Reversing optional maintainable actuator operation

NB: Requires a new positioner and air fittings (12) or plug (43)

1. Rotate cylinder (1).
2. Remove lock wire (10) and pull away cylinder (1).
3. Reverse stem (2) and spring assembly (14).
4. Fit plugs (9, 43) and air fitting (12) as shown on the drawing.
5. Re-assemble in reverse order (3 to 1).



*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

Data - valve/actuator	
Max. product pressure.....	10 bar (1000 kPa) (145 psi)
Min. product pressure.....	Full vacuum (depending on product specifications)
Temperature range	-10° C to + 140° C (standard EPDM seal)
Air pressure, actuator	5 to 7 bar (500 to 700 kPa) (72.5 to 101.5 psi)
Materials - valve/actuator	
Product wetted steel parts.....	AISI 316L (internal Ra < 0.8)
Other steel parts.....	AISI 304
Product wetted seals.....	EPDM (standard)
Optional product wetted seals	HNBR and FPM
Other seals	NBR


For positioner see Positioner manual


Data Positioner

General Specifications

Instrument Input Pressure Range.....	0.2-1 bar (standard) 0.2-0.6, 0.6-1, 0.6-1.8 bar (option)
Instrument Input Pressure, Maximum.....	1 bar (15 psi) for instrument input pressure spans of 0.8 bar (12 psi) or less and 1.8 bar (27 psi) for instrument spans of 1.2 bar (16 psi) or greater
Supply Pressure	
Minimum.....	0.2 bar above required actuator pressure
Maximum.....	7 bar
Air Consumption.....	17 l/min (in balance condition with 1.4 bar supply and 0.6 bar dead ended output)
Valve Travel	
Minimum.....	6.3 mm
Maximum.....	101 mm
Response Level	0.25% of scale (Output sensitivity to input pressure changes)
Ambient Temperature Limits	-10°C to +82°C (14°F to +284°F)

For parts lists please see section 6.1.
The drawings include all items.
NC = Normally closed
NO = Normally open





The parts list includes all items.

Parts List

Pos.	Qty.	Denomination	Denomination
6 ●	1	Actuator, complete	Servicekit/Actuator 9611-92-6737
7 ●	1	Bushing	
8 ●	2	O-ring	Service Kits/Product wetted parts
9	1	Plug (NO+NC)	38 mm/DN40
12	1	Air fitting (NC)	EPDM..... 9611-92-6502
19	1	Clamp	HNBR..... 9611-92-6508
20	1	Bonnet	FPM 9611-92-6514
21 Δ	1	O-ring	51 mm/DN50
22	1	Valve body	EPDM..... 9611-92-6503
			HNBR..... 9611-92-6509
23	1	Plug complete	FPM 9611-92-6515
23.1	1	Plug	
23.2 Δ	1	Plug seal	63.5 mm/DN65
			EPDM..... 9611-92-6504
24	1	Bushing	HNBR..... 9611-92-6510
25 Δ	1	Lip seal	FPM 9611-92-6516
42	1	Spring connection piece	
43	1	Plug (NO)	76.1 mm/DN80
44	1	Positioner yoke	EPDM..... 9611-92-6505
45 ●	1	Guide ring	HNBR..... 9611-92-6511
46	1	Spring	FPM 9611-92-6517
47	1	Positioner	
48	1	Air fitting (NC)	101.6 mm/DN100
49	2	Air fitting (NC+NO)	EPDM..... 9611-92-6506
			HNBR..... 9611-92-6512
			FPM 9611-92-6518

●: Service kits - Actuator

Δ: Service kits - EPDM



Δ: Service kits - HNBR


Δ: Service kits - FPM

The parts list includes all items.

NC = Normally closed.

NO = Normally open.





The parts list includes all items.

NC = Normally closed.

NO = Normally open.

Parts List

Pos.	Qty.	Denomination
1	1	Actuator, complete
2	1	Cylinder
3 ●	1	Piston
5	1	O-ring
6 ●	1	Adapter
7 ●	1	Bushing
8 ●	1	O-ring
9	2	O-ring
10	1	Plug (NO+NC)
11 ●	1	Lock wire
12	1	O-ring
14	1	Air fitting (NC)
15	1	Spring assembly
16 ●	1	Bottom
42	1	Support disc
43	1	Spring connection piece
44	1	Plug (NO)
45 ●	1	Positioner yoke
46	1	Guide ring
47	1	Spring
48	1	Positioner
49	1	Air fitting (NC)
13	2	Air fitting (NC+NO)
17	1	Yoke (not shown in drawing)
18	3	Washer (not shown in drawing)
	3	Nut (not shown in drawing)

●: Service kits - Actuator, NO, NC

Service Kits

Denomination	Item number
--------------	-------------

Service kit, actuator

1½"

NO, NC9611-92-6740

2" - 2½"

NO, NC9611-92-6741

3" - 4"

NO, NC9611-92-6742

How to contact Alfa Laval

Contact details for all countries are continually updated on our website. Please visit www.alfalaval.com to access the information direct.